





Dell Mobile Adapter Speakerphone

MH3021P

Quick Start Guide




Speakerphone




USB-A ports
(10Gbps)


USB-C cable




USB-C connector




NOTE: The mobile adapter supports only one display at a time.



Without Power Delivery




With Power Delivery Via USB-C Power Adapter



NOTE: The mobile adapter supports only one display at a time.

With Power Delivery Via USB-C Monitor



[Dell.com/support](https://www.dell.com/support)
[Dell.com/contactdell](https://www.dell.com/contactdell)
[Dell.com/regulatory_compliance](https://www.dell.com/regulatory_compliance)
Regulatory Model: MH3021Pu