


Jabra®

JABRA HALO SMART



User Manual

jabra.com/halosmart

A BRAND BY

GN Netcom

© 2016 GN Netcom A/S. All rights reserved. Jabra® is a registered trademark of GN Netcom A/S. All other trademarks included herein are the property of their respective owners. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GN Netcom A/S is under license. (Design and specifications subject to change without notice).

MADE IN CHINA
MODEL: OTE28



Declaration of Conformity can be found on www.jabra.com/CP/US/declarations-of-conformity

1. WELCOME	4
2. PRODUCT OVERVIEW	5
2.1 INCLUDED ACCESSORIES	
3. HOW TO WEAR.....	6
3.1 SHAPING THE NECKBAND	
3.2 GETTING THE CORRECT FIT	
3.3 USING THE MAGNETIC EARBUDS	
4. HOW TO CHARGE	9
4.1 BATTERY STATUS	
5. HOW TO CONNECT.....	11
5.1 TURNING THE HEADSET ON/OFF	
5.2 CONNECT TO YOUR MOBILE PHONE	
6. HOW TO USE	13
7.1 CALLS & MUSIC	
7.2 HEADSET VOICE GUIDANCE	
7.3 PHONE VOICE COMMANDS	
7.4 MULTIPLE CALL HANDLING	
7.5 VIBRATE ALERT	
7.6 HOW TO RESET THE HEADSET	
7. JABRA ASSIST APP	19
8. SUPPORT	20
8.1 FAQ	
8.2 HOW TO CARE FOR YOUR HEADSET	
9. TECHNICAL SPECIFICATIONS	21


1. WELCOME

Thank you for using the Jabra Halo Smart. We hope you will enjoy it!

JABRA HALO SMART FEATURES

- Best in Class talk time - Up to 17 hours of talk time, and up to 15 hours of music time
- Premium Call Experience - Integrated wind noise protection for calls anywhere
- Premium Wireless Sound - 10mm speakers
- All day durability - Dust and water resistance IP54 rated
- One Touch Voice Control - Dedicated Google now/Siri/Cortana button for instant voice commands
- All day comfortable fit - Contoured all day wearing design, with magnetic cord management
- Audio made smarter with announcements - Text message, Calendar and email read outs (Android phones)
- Never miss a call - Vibrate alert

2. PRODUCT OVERVIEW



2.1 INCLUDED ACCESSORIES



USB charging
cable



Large



Medium




Small



Extra
small


3. HOW TO WEAR

Halo Smart is designed to be worn around the neck.



3.1 SHAPING THE NECKBAND


The neckband can be shaped to fit your neck by bending the neckband at the Flex zones, for the ultimate comfort and stability.



3.2 GETTING THE CORRECT FIT


The headset is supplied with four EarGel sizes: large, medium, small and extra small.

It is highly recommended to find the EarGel that best fits your ear for the optimal sound experience. The correct EarGel will feel tight and will seal out background disturbances.




3.3 USING THE MAGNETIC EARBUDS

The earbuds can be magnetically snapped together for convenient cable management. When the earbuds are snapped together your music will be paused.



Alternatively, the earbuds can be magnetically attached to the neckband.



4. HOW TO CHARGE




To charge the headset, gently pull open the charging cover to expose the micro-USB charging port and connect to a power supply. It is recommended to charge the headset using the supplied Jabra charging cable, however it is possible to charge the headset using your mobile phone charger.

It takes approx. 2 hours to fully charge the headset.

NOTE: The lifetime of the battery may be significantly reduced if the headset is left uncharged for a long period of time. It is recommended to recharge the headset at least once a month.

4.1 BATTERY STATUS

To see and hear the current battery status, tap the **Volume up** or **Volume down** button when not listening to music or on a call.


WHAT YOU SEE	WHAT YOU HEAR	WHAT IT MEANS
	Full battery	50-100% battery
	Medium battery	20-50% battery
	Low battery	20% or below battery

5. HOW TO CONNECT

5.1 TURNING THE HEADSET ON/OFF


On: Press and hold the **Multi-function** button for 3 seconds. The LED will flash green.

Off: Press and hold the **Multi-function** button for 5 seconds. The LED will flash red.




5.2 CONNECT TO YOUR MOBILE PHONE

1. Turn on Bluetooth on your mobile phone.
2. Ensure that the headset is off, and then press and hold (5 secs) the **Multi-function** button until the LED flashes blue and you hear an announcement in the headset.
3. Wear the headset and follow the voice-guided connection instructions.




6. HOW TO USE



6.1 CALLS & MUSIC

CALLS & MUSIC



Multi-function Button

Turn on headset

Press and hold (3 sec) the **Multi-function** button

Turn off headset

Press and hold (5 sec) the **Multi-function** button

Play/pause music


Tap the **Multi-function** button

Answer/end call

Tap the **Multi-function** button

Reject call


Double-tap the **Multi-function** button



Magnetic earbuds

Answer/end call

Detach/attach the Magnetic earbuds



Volume up button

Volume down button

Adjust volume

Tap the **Volume up** or **Volume down** button, when listening to music or on a call

Skip track forward


Press and hold (1 sec) the **Volume up** button

Skip track backwards

Press and hold (1 sec) the **Volume down** button

Battery status

Tap the **Volume up** or **Volume down** button, when not listening to music or on a call



Voice button

Activate Siri/Google Now/Cortana

Tap the **Voice** button, when not on a call

Mute/un-mute microphone

Tap the **Voice** button, when on a call

6.2 HEADSET VOICE GUIDANCE


Headset voice guidance are voice announcements intended to guide you or give headset status updates (e.g. connection and battery status).

HOW TO TURN VOICE GUIDANCE ON/OFF

Voice guidance is enabled by default.

Voice Guidance On:

Ensure the headset is powered on, and then simultaneously press and hold the **Volume up** button and the **Voice** button for 3 seconds.




Voice Guidance Off:

Ensure the headset is powered on, and then simultaneously press and hold the **Volume down** button and the **Voice** button for 3 seconds.



6.3 PHONE VOICE COMMANDS (SIRI, GOOGLE NOW, CORTANA)

Phone voice commands enable you to speak to Siri/Google Now/Cortana on your mobile phone using your headset. For more information on using Siri, Google Now, or Cortana, please refer to your phone's user manual.




Activate Siri/Google Now/Cortana (phone dependent)

Tap the **Voice** button, when not on a call

6.4 MULTIPLE CALL HANDLING

The headset can answer or reject calls when you are already on a call.



End current call and answer incoming call

Tap the **Multi-function** button

Reject incoming call, when on a call

Double-tap the **Multi-function** button

Put current call on hold, and answer incoming call

Press and hold (1 sec) the **Multi-function** button


Switch between the current call and the call on hold

Press and hold (1 sec) the **Multi-function** button

6.5 VIBRATE ALERT

The headset will vibrate whenever it is powered on/off, connected to your mobile phone, or when there is an incoming call.

Vibrate Alert is enabled by default, and can be disabled using the Jabra Assist app (Android only).



6.6 HOW TO RESET THE HEADSET

Resetting the headset will clear the list of connected devices.

Reset the headset: Ensure the headset is powered on, and then simultaneously press and hold the **Volume up** button and the **Multi-function** button for 5 seconds. You will then need to restart the headset.

7. JABRA ASSIST APP

The Jabra Assist app is a free app for iOS or Android devices that enables you to:

- Enable/disable vibration
- Enable/disable message read-out
- And more..



Jabra Assist

Android download - Google Play
iOS download - App Store

8. SUPPORT

8.1 FAQ

View the FAQs on jabra.com/halosmart

8.2 HOW TO CARE FOR YOUR HEADSET

- Always store the headset with the power off and safely protected.
- Avoid storage at extreme temperatures (above 85°C/185°F or below -20°C/-4°F). This can shorten battery life and may affect the headset.

9. TECHNICAL SPECIFICATIONS

JABRA HALO SMART	SPECIFICATION
Weight:	38 g (1.34 oz)
Dimensions:	L 159 mm x W 43 mm x H 179 mm
Microphones:	Omni-directional microphone
Microphone frequency range:	200 Hz - 6.3 kHz
Microphone SLR:	10dB +/- 5dB
Speaker type:	10 mm neodymium magnet speaker
Speaker sensitivity:	97 ±3dB/mW at 1 KHz
Speaker impedance:	16 ohm
Speaker max input power:	8 mW
Speaker frequency range:	20 Hz - 20 kHz
Operating range:	Up to 10 m/33 ft (phone dependent)
Bluetooth version:	4.0
Paired devices:	Up to 8, connected to two at the same time (MultiUse™)

JABRA HALO SMART	SPECIFICATION
Supported Bluetooth profiles:	Headset profile (v1.2), hands free profile (v1.6), A2DP (v1.2), AVRCP (v1.4)
Talk time:	Up to 17 hours
Music time:	Up to 15 hours
Standby time:	Up to 22 days
Charging time:	Approx. 2 hours
Operating temperature:	-10°C to 55°C (15°F to 131°F)
Storage temperature:	-20°C to 85°C (-4°F to 185°F)
Pairing passkey or PIN:	0000
Product materials:	Silicone, PC/ABS, PMMA, PA, PET, TPE and TPU

